

RC-codes (2010 models: xxPFLxxx5x/xx)	Remarks
	INFO ONLY: This chapter describes all RC commands which shall be supported by the TV, including the commands present on the regular RC delivered with the TV.
	The TV shall support following RC commands in given format: <protocol> - <system>, <code> - <name/ [alternative names]>
RC6 - 000,012 - Standby	
RC6 - 000,010 - Previous channel / P<P / Back	
RC6 - 000,204 - Browse / Guide	
RC6 - 000,109 - Red colour	
RC6 - 000,110 - Green colour	
RC6 - 000,111 - Yellow colour	
RC6 - 000,112 - Blue colour	
RC6 - 000,088 - Cursor up	
RC6 - 000,089 - Cursor down	
RC6 - 000,090 - Cursor left	
RC6 - 000,091 - Cursor right	
RC6 - 000,092 - Confirm / OK	
RC6 - 000,084 - Home	
RC6 - 000,016 - Volume up / V+	
RC6 - 000,017 - Volume down / V-	
RC6 - 000,000..009 - Digit [0..9]	
RC6 - 000,144 - Ambient mode / Experience	Diversity: AL Region: All
RC6 - 000,013 - Mute	Region: All
RC6 - 000,064 - Options	Region: All
RC6 - 000,159 - Tuner A / Watch TV / Exit	Region: All
RC6 - 000,076 - Next	Region: All
RC6 - 000,077 - Previous	Region: All
RC6 - 000,217 - Dot	Diversity: ATSC Region: AP-NTSC, NAFTA, Latam
RC6 - 000,015 - Info / i+	Region: Latam
RC6 - 000,063 - TV system Rationale: Used as Power On.	Region: All
RC6 - 000,060 - Teletext	Region: Europe, AP-PM
RC6 - 000,056 - Next source / Source	Region: All
RC6 - 000,245 - Viewmode / Picture format	Region: All
RC6 - 000,143 - Ambient on/off	Diversity: AL Region: All
RC6 - 000,015 - Info / i+	Region: Europe, AP-PM
RC6 - 000,044 - Play/Pause / Play	Region: All
RC6 - 000,040 - Fast forward / ffw	Region: All
RC6 - 000,049 - Stop	Region: All
RC6 - 000,043 - Rewind / rew	Region: All
RC6 - 000,055 - Record	Region: All
RC6 - 000,075 - Subtitle	Region: Europe, AP-PM
RC6 - 000,190 - Online / Net TV	Diversity: OIS Region: All
RC6 - 000,070 - ClosedCaptions	Region: AP - NTSC, NAFTA, Latam
Discrete Remote Codes for zapping to extensions The TV shall support discrete RC5 commands to directly zap to any extension (including Front/Side, HDMI,...). Rationale: Users (& special dealers) have to be able to make special applications with our TVs and they want to be able to select directly certain functions, like direct selection of externals, screen formats etc. (so direct RC codes). The commands: RC5 3,05 and 3,58 Side/Front RC5 3,04: Ext1 RC5 0,57: Ext2 RC5 3,56: Ext3 RC5 3,57: Ext4 RC5 3,123: Ext5 RC5 3,06: Ext6 RC5 3,07: Ext7 RC5 3,08: Ext8 Remark: The extension numbers above refer to all inputs of all regions - the exact connector depends on connectivity configuration	Region: All
Discrete Remote Codes for View modes The TV shall support discrete RC5 commands to directly change to any viewmode. Rationale: Users (& special dealers) have to be able to make special applications with our TVs and they want to be able to select directly certain functions, like direct selection of externals, screen formats etc. (so direct RC codes). The commands: RC5 3,61: Autofill RC5 3,62 : Movie Expand 16by9 RC5 3,80 : Autozoom RC5 3,81: Cinema 21by9 RC5 3,83: SuperZoom 16by9 RC5 3,85: Cinema 21by9 Subtitle RC5 3,116 : 16by9 RC5 3,117 : Unscaled RC5 3,125: Superzoom RC5 3,126 : Widescreen	Region: All
Discrete Remote Codes for Applications The TV shall support the following RC codes for activating sources and their applications: RC5, 3.19: USB mode (USB content browser) RC5, 3.96: Mediaserver select (DLNA content browser) RC5, 3.97: Internet browser select Remark: These only apply if the corresponding source related application is supported in the TV.	Region: All

Discrete codes for 2D / 3D: RC6 - 0.020 / RC5 - 3,020 - 2D RC6 - 0.021 / RC5 - 3,021 - 3D	Region: All
RC5 - 0,12 - Standby	Region: All
RC5 - 0,63 - TV system / Power On (RC6 - 000,063 - TV system)	Region: All
RC5 - 3,72 - Tuner A / Watch TV	Region: All
RC5 - 0,34 - Previous Programme / P<P / Back	Region: All
RC5 - 3,44 - Browse / Guide	Diversity: EPG or EPG-ATSC Region: All
RC5 - 0,107 - Red colour	Region: All
RC5 - 0,108 - Green colour	Region: All
RC5 - 0,109 - Yellow colour	Region: All
RC5 - 0,110 - Blue colour	Region: All
RC5 - 0,111 - White colour	Region: All
RC6 - 000,113 - White colour	Region: All
RC5 - 0,80 - Cursor up	Region: All
RC5 - 0,81 - Cursor down	Region: All
RC5 - 0,85 - Cursor left	Region: All
RC5 - 0,86 - Cursor right	Region: All
RC5 - 0,87 - Confirm / OK	Region: All
RC5 - 0,82 - Home	Region: All
RC5 - 0,60 - Teletext	Region: Europe, AP-PM
RC5 - 0,16 - VolumeUp	Region: All
RC5 - 0,17 - VolumeDown	Region: All
RC5 - 0,32 - ChannelStepUp (P+)	Region: All
RC5 - 0,33 - ChannelStepDown (P-)	Region: All
RC5 - 0,0,9 - Digit (0..9)	Region: All
RC5 - 0,56 - NextSource	Region: All
RC5 - 0,126 - ViewMode	Region: All
RC5 - 0,71 - Ambilight on/off	Diversity: AL Region: All
RC5 - 0,73 - Ambilight mode/Experience	Diversity: AL Region: All
RC5 - 0,13 - Mute	Region: All
RC5 - 0,15 - Info / i+	Region: All
RC5 - 0,53 - Play/pause / Play (RC6 - 000,193 - Play/Pause / Play)	Region: All
RC5 - 0,52 - Fast forward / ffw	Region: All
RC5 - 0,54 - Stop	Region: All
RC5 - 0,50 - Rewind / rew	Region: All
RC5 - 0,112 - Next	Region: All
RC5 - 0,113 - Previous	Region: All
RC5 - 0,61 - Power off	Diversity: not CEC Region: All
RC5 - 0,61 - System standby Rationale: Wanted for programmable remotes.	Diversity: CEC Region: All
RC6 - 000,061 - System standby Rationale: Wanted for programmable remotes.	Diversity: CEC Region: Europe APPM
RC6 - 000,061 - Power off Rationale: Wanted for programmable remotes.	Diversity: not CEC Region: All
RC5 - 3,40 - Ambilight on	Diversity: AL
RC5 - 3,41 - Ambilight off	Region: All
RC5 - 0,58 - ClosedCaptions	Region: AP-NTSC, NAFTA, Latam
RC5 - 0,58 - Subtitle	Region: Europe, AP-PM